



Path Finder

The Path finder has the following modes: time, compass, chrono, chrono recall, timer, and alarm.

TIME WARP

Time warp: hold for 1.5 seconds in any mode to return to time mode.

TIME MODE

Toggle between Celsius and Fahrenheit temperature by pressing S1 and holding for 4 seconds

- Toggle between time zone T1 and T2... press and hold S2 for 4 seconds
- To set time press and hold S4 for 4 seconds. Press S3 to change from hour, minute, second, year, month, day, and 12/24hr, press S1 and S2 for plus / minus.

COMPASS MODE

- Press S3 until you reach compass
- Must calibrate often for accuracy. Press and hold S4 for 4 seconds. Keeping the watch as horizontal as possible, turn the watch in the direction of the arrow two turns, 15 seconds per turn. Press S1 to confirm without declination setting, press S1 to confirm without declination, press S1 and S2 for plus / minus, press S3 to go from single digit degrees by 10, then direction press S4 to exit.
- Compass will hold reading for 10 seconds, press S1 to reactivate.
- Trakkak function, face the 12 o'clock side of the watch in the direction of destination and press S2, hold the watch in the same direction and hold and press S1 for 3 seconds. You have locked in a target bearing see blinking triangle
- When you have reached the destination, press S2 the watch will switch directions back to the starting point. The blinking triangle is now locked in on the original starting point
- When you arrive at starting point press S2 to revert to Compass function.

CHRONO MODE

Chrono Mode - 24hour chronograph, 50lap memory, 10run data storage

- Press S3 until you reach "Chrono"
- Press S1 to start "Chrono" see stopwatch icon blinking
- Press S1 for laps.....lap time will display for 6seconds
- Press S2 to stop the run.
- Press and hold S2 for 3 seconds to save the run and reset the chronograph
- Press and hold S4 for 4 seconds to clear and reset the chronograph.

CHRONO RECALL MODE

10run data storage view laps best lap and average lap

- Press S2 to scroll through saved runs
- Press S1 to view data of selected run
- Press and hold S4 for 4 seconds to delete selected run
- press and hold S4 for 8seconds to clear all runs

TIMER MODE

- two 24 hour countdown timers
- Press S3 until you reach "Timer"
- Press and hold S4 for 4 seconds to set timer
- Press S3 to set seconds, minutes, hours, then segments. -
- Press S1 and S2 for plus/minus.
- Press S2 to select segment.
- Press S1 to start countdown timer. Timer will switch automatically to other segment timer.

ALARM MODE

- dual alarm
- Press S3 until you reach "Alarm"
- Press S2 to select alarm
- Press S1 to turn alarm on or off
- Press and hold S4 for 4 seconds to set alarm
- Press S3 to set hour, minute, then chime. Press S1 and S2 for plus / minus.

BATTERY LIFE:

The battery in your watch is estimated to last 2 years, depending on frequency and use of certain features.

BATTERY REPLACEMENT:

Battery replacement must be performed by an authorized service center to retain a valid warranty. In addition to battery replacement, the service center will test movement, gaskets, water resilience and hardware, to further ensure the long-term care of your watch.

WARNING!

Keep watch batteries away from children. If swallowed, contact a doctor immediately.

WARNING! Batteries contain chemical substances. They should be disposed of properly according to local regulations.

WATER RESISTANCE: 50 meters

ATTENTION: Water damage may occur if the buttons are pressed underwater.

OPERATING TEMPERATURE: -5 to 50°C Celsius



PF-01-AA(11-227)



PF-01-AF(11-227)



PF-01-AD(11-227)



PF-01-AC(11-227)



PF-01-AB(11-227)



PF-01-AG(11-227)

CASE DIMENSION: 50 (mm) X 50 (mm) X14 (mm)

WEIGHT: 69 g



Path Finder

The Path finder has the following modes: time, compass, chrono, chrono recall, timer, and alarm.

TIME WARP

Time warp: hold for 1.5 seconds in any mode to return to time mode.

TIME MODE

Toggle between Celsius and Fahrenheit temperature by pressing S1 and holding for 4 seconds

- Toggle between time zone T1 and T2... press and hold S2 for 4 seconds
- To set time press and hold S4 for 4 seconds. Press S3 to change from hour, minute, second, year, month, day, and 12/24hr, press S1 and S2 for plus / minus.

COMPASS MODE

- Press S3 until you reach compass
- Must calibrate often for accuracy. Press and hold S4 for 4 seconds. Keeping the watch as horizontal as possible, turn the watch in the direction of the arrow two turns, 15 seconds per turn. Press S1 to confirm without declination setting. Press S1 to confirm without declination. Press S1 and S2 for plus / minus. Press S3 to go from single digit degrees by 10, then direction press S4 to exit.
- Compass will hold reading for 10 seconds, press S1 to reactivate.
- Trakbak function, face the 12 o'clock side of the watch in the direction of destination and press S2, hold the watch in the same direction and hold and press S1 for 3 seconds. You have locked in a target bearing see blinking triangle
- When you have reached the destination, press S2 the watch will switch directions back to the starting point. The blinking triangle is now locked in on the original starting point
- When you arrive at starting point press S2 to revert to Compass function.

CHRONO MODE

Chrono Mode- 24hour chronograph, 50lap memory, 10run data storage

- Press S3 until you reach "Chrono"
- Press S1 to start "Chrono" see stopwatch icon blinking
- Press S1 for laps.....lap time will display for 6seconds
- Press S2 to stop the run.
- Press and hold S2 for 3 seconds to save the run and reset the chronograph
- Press and hold S4 for 4 seconds to clear and reset the chronograph.

CHRONO RECALL MODE

10run data storage view laps best lap and average lap

- Press S2 to scroll through saved runs
- Press S1 to view data of selected run
- Press and hold S4 for 4 seconds to delete selected run
- Press and hold S4 for 8seconds to clear all runs

TIMER MODE

- two 24 hour countdown timers
- Press S3 until you reach "Timer"
- Press and hold S4 for 4 seconds to set timer
- Press S3 to set seconds, minutes, hours, then segments. -
- Press S1 and S2 for plus/minus.
- Press S2 to select segment.
- Press S1 to start countdown timer. Timer will switch automatically to other segment timer.

ALARM MODE

- dual alarm
- Press S3 until you reach "Alarm"
- Press S2 to select alarm
- Press S1 to turn alarm on or off
- Press and hold S4 for 4 seconds to set alarm
- Press S3 to set hour, minute, then chime. Press S1 and S2 for plus / minus.

BATTERY LIFE:

The battery in your watch is estimated to last 2 years, depending on frequency and use of certain features.

BATTERY REPLACEMENT:

Battery replacement must be performed by an authorized service center to retain a valid warranty. In addition to battery replacement, the service center will test movement, gaskets, water resilience and hardware, to further ensure the long-term care of your watch.

WARNING!

Keep watch batteries away from children. If swallowed, contact a doctor immediately.

WARNING! Batteries contain chemical substances. They should be disposed of properly according to local regulations.

WATER RESISTANCE: 50 meters

ATTENTION: Water damage may occur if the buttons are pressed underwater.

OPERATING TEMPERATURE: -5 to 50°C Celsius



PF-02-AA(06-016)



PF-02-KA(06-016)



PF-02-AF(06-016)



PF-02-KC(06-016)



PF-02-AC(06-016)



PF-02-AJ(06-016)

CASE DIMENSION: 45 (mm) X 45 (mm) X14 (mm)

WEIGHT: 52 g